

MLS DestinAtor

ΤΟ ΚΟΡΥΦΑΙΟ ΣΥΣΤΗΜΑ ΠΛΟΗΓΗΣΗΣ



USER MANUAL

- MLS Destinator **Pro 3860A**
- MLS Destinator **Pro 4810A**
- MLS Destinator **Pro 4810ABT**



WARNING

Avoid leaving your device connected to power supply. Overcharging may decrease battery life

Contents

| | |
|----------------------------------|----|
| PRECAUTION AND NOTICE | 04 |
| INSIDE THE BOX | 04 |
| A. BASIC INTRODUCTION | 05 |
| 1. OVERVIEW | 05 |
| 2. ACCESSORY OPERATIONS | 07 |
| 2.1 Charging by car charger | 07 |
| 2.2 Install the car mount system | 08 |
| 2.3 USB cable usage | 08 |
| 3. GPS INITIAL START UP | 09 |
| B. FUNCTIONS OPERATION | 09 |
| POWER ON & OFF | 09 |
| MAIN MENU | 09 |
| Navigation (Πλοήγηση) | 09 |
| Music (Μουσική) | 10 |
| Photo (Φωτογραφίες) | 11 |
| Ebook (Βιβλίο) | 12 |
| Video (Βίντεο) | 13 |
| Bluetooth | 15 |
| 1. Call record | 16 |
| 2. Pairing | 16 |
| 3. Settings | 17 |
| 4. Paired devices | 18 |
| System (Σύστημα) | 18 |

Precaution and notice

□ GPS is operated and controlled under the sole responsibility of the Government of the United States of America, who are responsible for its availability and accuracy. Any changes in GPS availability and accuracy, or in environmental conditions, may impact the operation of your device. We can not accept any liability for the availability and accuracy of GPS.

□ The PND is used only as a navigation aid. It is not for precise measurement of direction, distance, location or topography. The user must follow all traffic signs and local regulations along the roads.

□ GPS satellite signals cannot pass through solid materials (except glass). When you are inside a tunnel or building, GPS position is not available.

□ A minimum of 4 GPS satellite signals are needed to determine current location. Signal reception can be affected by situations such as bad weather or wireless devices or dense overhead obstacles (e.g. tall buildings).

□ When you get out of the car, do not leave your PND on the dashboard or subject to direct sunlight. The overheating of the battery may cause malfunctions and/or dangerous conditions.

□ For your own safety, do not operate the controls of the PND while driving. Do not mount where the driver's field of vision is blocked

Inside the box

- Portable navigation device (PND) with navigation software and maps
- Car mount system
- Car charger
- User manual
- Software manual
- USB cable

A. Basic Introduction

1. Overview


3860A



- (1) LCD charging indicator
- (2) ON/OFF button
- (3) Speaker
- (4) SD/MMC slot
- (5) Auto brightness sensor
- (6) Reset button
- (7) MiniUSB Port

1. Overview

4810A - 4810ABT



- (1) LCD charging indicator
- (2) ON/OFF button
- (3) Speaker
- (4) SD/MMC slot
- (5) Earphone jack
- (6) Reset button
- (7) MiniUSB port
- (8) Auto brightness sensor


Do not expose the device to high temperature. Avoid exposing the unit to direct sunlight for long period of time or leaving it inside a parked car for many days under sunlight. Extreme temperature may cause permanent damage.

Warranty is void if device has been disassembled or modified.

2. Accessory operations

2.1 Charging by car charger

- We recommend plugging the device to car charger when using it in the car.
- Plug the car charger into the device's USB port on its side panel. Plug car charger's the other end into the car igniter.
- Adjust the cable so as not to block driver's view.



(1) Put this end to device MiniUS port

(2) Put this end to car igniter

2.2 Install the car mount system

Place the device on the holder (1) and install into the car cradle. Take off the protected film (if exist) on the bottom of the suction. Make sure the window or the suction or windscreen is clean and dry. Put the bracket onto a suitable location of your windscreen or side window. Press the lever (2) to lock the suction onto the surface. Use the two screws to adjust the angle and direction for the PND.



2.3 USB cable usage

- The USB cable is provided for system upgrades. This USB cable will work on the PC either with Microsoft Active Sync® or as a mass storage media. You can select the mode in the "System-Sys Info-USB" menu.
- For latest version and information concerning Microsoft Active Sync, please visit www.microsoft.com.



3. GPS initial start up

For the first time to start up the navigation program, the device shall be operated in an open area without obstructions.

Hold the device still until it receives a valid GPS signal, and then you can start your program as you wish.

Note:

There are various ways for searching a location on the map or planning your routing. See navigation user manual which guides you through the process of running this function in detail

B. Functions operation

Power On & Off

Longtime press the power switch on the top panel to power on the device. Press the same button to switch off the device.

Main interface



Navigation (Πλοήγηση)

Tap the icon navigation to enter the navigation software. Operating instructions for the navigation software you will find inside the the MLS Destinator software manual.

Music (Μουσική)

1. Tap the icon "Music (Μουσική)".



2. Double tap the music file you want to play.



- (A) Return to the main menu
- (B) Repeat
- (C) Random play
- (D) Volume level
- (E) Return to previous menu
- (F) Next track
- (G) Previous track
- (H) Stop
- (I) Speed bar
- (J) Pause

Photo (Φωτογραφίες)

1. Tap the icon "Photo (Φωτογραφίες)" in submenu "Media (Πολυμέσα)".



2. Double tap the image file you want to display.



- (A) Previous
- (B) Next
- (C) Return to previous menu
- (D) File name
- (E) Exit
- (F) Zoom in
- (G) Zoom out
- (H) Rotate
- (I) Full screen

Tap the FULL SCREEN icon and enter into full screen mode




Tap the icons NEXT and PREVIOUS to browse images. If the image's format or dimensions are not supported the device will display black screen.



Ebook (Βιβλίο)

1. Tap the icon "E-book (Βιβλίο)" to enter the e-book submenu.




2. Double tap the selected file and the below screen will appear:



- (A) Return to main menu
- (B) Previous
- (C) Next
- (D) Return to previous menu
- (E) Select page
- (F) File name
- (G) Current page/total pages

Video (Βίντεο)

1. Tap the icon "Video (Βίντεο)" to enter the video submenu.




2. Double tap the selected video file.



- (A) Return to main menu
- (B) Pause
- (C) Stop
- (D) Speed up
- (E) Volume level
- (F) Full screen
- (G) Return to previous screen
- (H) Speed bar


Tap the FULL SCREEN icon and enter into full screen mode



When in full screen mode, double tap the screen once more to return to normal view.



Bluetooth

Tap the icon "Bluetooth"  to enter the bluetooth submenu.



Tap  to return to main menu.

Tap the icon  to enter the following screen.



- (A) Return to previous menu
- (B) Correction
- (C) Connect with mobile phone
- (D) Call record



1. Call record


Tap the icon  to enter following screen.



- (A) Return to previous menu
- (B) Unanswered calls record
- (C) Scroll Up
- (D) Scroll down
- (E) Make call
- (F) Clear call record
- (G) Delete selected call
- (H) Incoming calls record
- (I) Outgoing calls record


2. Pairing

Tap the icon  or  to enter the following screen.



3. Settings

Tap the icon  to enter the following screen.



(A) Set password

(B) Select ringtone



Tap the icon  to enter the following screen.

Afterwards select the desired ringtone from the available list.



4. Paired devices


Tap the icon  to enter the following screen.



- (A) Previous
- (B) Next
- (C) Clear all paired devices
- (D) Disconnect selected device
- (E) Connect selected device

System (Σύστημα)

Tap "System (Σύστημα)" to enter settings submenu:




1. Backlight (Φωτισμός)

Tap "Backlight (Φωτισμός)" to adjust backlight. By checking Auto-Brightness, backlight is automatically adjusted according to the ambient light.



2. System Info (Πληροφορίες συστήματος)

Tap "System Info (Πληροφορίες Συστήματος)" to enter the according submenu.




- You can calibrate the touch screen if it is not corresponding precisely to your touch.

-
1. Tap Calibration from the subselection System Info
 2. Follow the displayed instructions.
 3. Press and hold at the center of the cross.
 4. Follow the cross to the next position.
 5. Repeat previous step till the final position of the cross.




3. Language (Γλώσσα)

Tap "Language (Γλώσσα)" to enter the following interface.




4. Power (Ενέργεια)

Tap "Power (Ενέργεια)" to enter the following interface.




5. Volume (Ένταση)

Tap "Volume (Ένταση)" to enter the following interface.



6. Date and Time (Ημερομηνία και ώρα)


Tap "Date and Time (Ημερομηνία και Ώρα)" to enter the following interface.



A. Tap "Date (Ημερομηνία)" and use the icons "<" or ">" γto set the date.



B. Tap "Time (Ωρα)" and use the icons "<" or ">" to set the time.





Technical Support
2310 989838

MLS MULTIMEDIA SA. THESSALONIKI: 79 17th Noemvriou st., 54352 Pylea // Phone : 2310.929090 // fax: 2310.937222
ATHENS: 40st Digeni Akrit & Argiroupoleos // 16451 Argiroupoli // Phone 210.9902570-71 // fax: 210.9642845
e-mail: mail@mls.gr // Web site: www.mlsdestinator.gr // www.mls.gr // Stock Symbol: MLS